



Chef's Planet Nonstick Toaster Ovenliner

With innovative, problem-solving kitchenware, Chef's Planet believes you can balance cooking with a busy life and are constantly thinking of new ways to make cooking simpler and more enjoyable!

Chef's Planet toaster ovenliner is a time saver and a drip and crumb catcher. No need to use chemical cleaners, nor that time-consuming self-cleaning oven cycle. They can be easily trimmed to fit on the rack. Best of all, it's MADE IN THE USA!



Tips/Instructions

1. Remove toaster ovenliner from package and place against toaster oven tray or toaster oven base to measure dimensions and determine whether you need to cut down to size.
 2. Cut down the toaster ovenliner down to size using scissors to necessary dimensions.
 3. Position toaster ovenliner on toaster oven tray or toaster oven base and enjoy the incredibly easy cleanup every time you use your toaster oven!
- * Just remove the nonstick liner and wipe clean or throw it in the dishwasher!

Notes
